



FIREMASTER® WILDLAND

Manufactured in Accordance to EN659:2003 + A1:2008

USER INFORMATION GUIDE

Carefully read these instructions before using this product

Version 2.0, Apr 2015

SOUTHCOMBE BROTHERS LTD • STOKE-SUB-HAMDON • SOMERSET • TA14 6QD • UK

T: +44 (0) 1935 823 567 • F: +44 (0) 1935 822 918
E: SALES@SOUTHCOMBE.COM • W: SOUTHCOMBE.COM

DESCRIPTION:

This product is an EN659:2003 certified fire-fighting glove with a cowhide grain leather outer, a Nomex® Delta T back and a seamless Kevlar® blend knitted lining, to give a high degree of protection. It is classified as Personal Protective Equipment (PPE) by the European PPE Directive 89/686/EEC and is shown to comply with this directive through the Harmonised European Standard.

END USE

The glove has been designed to offer the wearer a high degree of protection against heat, fire, water, oil, chemicals, cuts and slashes in accordance with EN659:2003 + A1:2008.

MATERIALS

LEATHER SPECIFICATION: Bovine grain leather, 1.3 mm thick BACK: Nomex Delta T (75% Nomex®, 23% Kevlar®, 2% antistatic fibres) LINING: Seamless knitted Kevlar® & glass-fibre with Viloft®. 480gm² THREAD: Nomex® & Twaron®

CUFFING (Wristlet model): Rib knitted cuffing (95% Nomex®, 5% Kevlar®)

FITTING & SIZING:

Always ensure that the correct size is selected. Products which are either too loose or too tight will not provide the optimum level of protection and will compromise dexterity. Measure the hand in inches around the circumference of the widest part of the dominant hand over the knuckles and inside the crotch of the thumb in inches and equate to the table below.

XXS	XS	S	M	L	XL	XXL
6	7	8	9	10	11	12

Sizes are in accordance with BS EN 420:2003.

USAGE

Structural fire fighting as certified to EN659:2003 + A1:2008. See EC Type Examination Certificate for more details.

MARKING

The Product is marked with

- Identification of the manufacturer, product code and size
- Material contents
- EN Certification & CE mark including pictograms
- · Care instructions
- Wearer warning notice

CLEANING & DRY PROCEDURE:



Machine washing is not recommended. Gloves should be washed by putting them on your hands, apply a small amount of mild liquid detergent of a neutral ph and rub briskly together. Rinse in warm water (max. 40°C). A sponge, not a stiff brush, is recommended for ingrained grime.

CONTAMINATED GLOVES:

If the gloves become contaminated they should be removed, bagged and isolated and either cleaned using the above procedure or disposed of in accordance with local health and safety standards.

DAMAGED GLOVES:

If gloves become damaged they will not provide optimum levels of protection and therefore should be immediately removed from service and replaced. Never try to repair gloves. If in any doubt, consult with the manufacturer before proceeding with corrective action.

STORING GLOVES:

When not in use, store the product in a well ventilated area away from extremes of temperature. Never place heavy objects on top of them. Always clean and dry your gloves before storing. Never leave in pockets of garments. Never store your gloves in direct sunlight, indirect sunlight or fluorescent light. Exposure can weaken and damage the materials in your gloves, particularly blends of aramid used in the knitted linings and cuff.

WARNING

No item of PPE will give the wearer 100% protection. Only wear a glove of the correct size. Inspect the glove for damage before use. Never wear a damaged glove, particularly when the leather outer shell has been pierced.

CERTIFICATION BODY:

The notified body carrying out the EC type examination and ongoing conformity is Satra Technology Centre, Wyndham Way, Telford Way, Kettering, Northamptonshire, NN16 8SD. United Kingdom. Notified body number 0321.